

Solutions for "network connection time out"

- 1. Check if the computer connected to network
- 2、Check if the reticle of BCS100 is connected



The direction of reticle









3、Set the IP address of BCS100

The local connection IP address and BCS100 IP address need to be at the same segment (10.1.1.XXX) and not repeat

Solution 1:

Open Config Tool FAREIR, click , enter IP address, then click 23.

2	Machine Config Tool(BMC1604)	X
Import Save Mac	Chine Org Lase Follower Gas Alarms Inport Outport BCP5045	
Machine 🛞	Follower	
General Org	BCS100	
Devices 🛞	Network Config: (3) IP Addr: 10.1.1.188	
Laser Follower	Test network connection	
Gas Focus Control	Set IF Addr of computer Inits camputer Inits alled 2 netcards. Network Card Name: 本的主義 2 max. 00-271.81.3197-80-06 IP: 1172.16.1.198	
Edge Seek	▲ Hetwork Lara Anale: Litetootn Mostll主技 MAC: C4→17F2F56-05-55 IP: 169.254.224.57	
10 🛞		
Alarms Inports		
Outports		
File Location 🙁		
File Location		
		A
		P





Solution 2 :

Open the software

, do the steps as shown below:



Enter IP address 10.1.1.188 and test network connection (010.001.001.188 this format will not work)

CS100 network conf	ig		
IP Address 10.1.1.188			
Test network	🖌 ок	× Cancel	

www.bodor.com / 86-531-88690051



Solution 3 :

(1) as shown in pic 1 , press F2 enter parameter setting interface

②as shown in pic 2, press 6 enter network setting interface

③as shown in pic 3, set IP address as 10.1.1.188, choose F1(on), save

BC	S100 V3.0	Pic	1								
1					一冊	F1			2	3	
	Stopped H*+00.80	LV.17	IF1J CALI IF2J PARA	BRATE	IGHT	F2	4	T	5	6	
	C +062978	88(-0056)	IF3J TEST	NCE	CONTR	F3	7	Ι	8	9	
			. 1.			F4	·		0	-	
	SHUT	FAST	+0.1	STOP		SHF	•		E	VT	
	FOLLOW	SLOW	-0.1	ORG		T			ESU	2	
)											6



4







